

スタジオシアターDMXアドレス表

1	FC上	1	31	FC下	15	61	TB1	17	91	TB2	15	121	SUS1	13	151	客SUS1	11
2		2	32		16	62		18	92		16	122		14	152		12
3		3	33	FC奥上	1	63		19	93		17	123		15	153		13
4		4	34		2	64		20	94		18	124		16	154		14
5		5	35		3	65		21	95		19	125	SUS2	1	155		15
6		6	36		4	66		22	96		20	126		2	156		16
7		7	37	FC奥中	1	67		23	97		21	127		3	157	客SUS2	
8		8	38		2	68		24	98		22	128		4	158		2
9		9	39		3	69		25	99		23	129		5	159		3
10		10	40		4	70		26	100		24	130		6	160		4
11		11	41	FC奥下	1	71		27	101		25	131		7	161		5
12		12	42		2	72		28	102		26	132		8	162		6
13		13	43		3	73		29	103		27	133		9	163		7
14		14	44		4	74		30	104		28	134		10	164		8
15		15	45	TB1	1	75		31	105		29	135		11	165		9
16		16	46		2	76		32	106		30	136		12	166		10
17	FC下	1	47		3	77	TB2	1	107		31	137		13	167		11
18		2	48		4	78		2	108		32	138		14	168		12
19		3	49		5	79		3	109	SUS1	1	139		15	169		13
20		4	50		6	80		4	110		2	140		16	170		14
21		5	51		7	81		5	111		3	141	客SUS1	1	171		15
22		6	52		8	82		6	112		4	142		2	172		16
23		7	53		9	83		7	113		5	143		3	173	客SUS3	1
24		8	54		10	84		8	114		6	144		4	174		2
25		9	55		11	85		9	115		7	145		5	175		3
26		10	56		12	86		10	116		8	146		6	176		4
27		11	57		13	87		11	117		9	147		7	177		5
28		12	58		14	88		12	118		10	148		8	178		6
29		13	59		15	89		13	119		11	149		9	179		7
30		14	60		16	90		14	120		12	150		10	180		8

※Add:221～250、Add:303以降空き

ST204 Ver.2 2021.03.01

スタジオシアターDMXアドレス表

181	客SUS3	9	211	GC下	7	241			271	客S2 LED	7	301	ライン1F	下 客席			
182		10	212		8	242			272		8	302		下 舞台			
183		11	213		9	243			273		9	303					
184		12	214		10	244			274		10						
185		13	215		11	245			275		11						
186		14	216		12	246			276		12						
187		15	217		13	247			277	作業灯	1S						
188		16	218		14	248			278		2TB						
189	GC上	1	219		15	249			279	ライトブリッジ	1						
190		2	220		16	250			280		2						
191		3	221			251	LH	in	281		3						
192		4	222			252		R	282		4						
193		5	223			253		G	283		5						
194		6	224			254		B	284		6						
195		7	225			255		I	285		7						
196		8	226			256		L	286	前室上							
197		9	227			257		St	287	前室下							
198		10	228			258	UH	in	288	サイド1F	上 客席						
199		11	229			259		R	289		上 舞台						
200		12	230			260		G	290		下 客席						
201		13	231			261		B	291		下 舞台						
202		14	232			262		I	292	サイド2F	上						
203		15	233			263		L	293		下						
204		16	234			264		St	294	LB	上						
205	GC下	1	235			265	客S2 LED	1	295		下						
206		2	236			266		2	296	2F客席							
207		3	237			267		3	297	ライン2F	上						
208		4	238			268		4	298		下						
209		5	239			269		5	299	ライン1F	上 客席						
210		6	240			270		6	300		上 舞台						

※Add:221～250、Add:303以降空き

ST204 Ver.2 2021.03.01